ABC COMPANIES
Exclusive U.S. VANHOOL Distributor

TECH TIPS
#1304

COACH MODEL :	All Models With Fuel Shutoff Valves
DATE :	4/02/2013
SUBJECT :	Fuel shutoff valve override procedure

Emergency operation of automatic shut-off valves in fuel supply

Introduction:

For safety, the fuel system has been equipped with two automatic solenoid shut-off valves. One in the supply line to the engine and one in the supply line to the coolant heater.

Location of shut-off valves

Location of shut-off valves varies by model and can be found in the operators manual, refer to "Access doors and controls on the outside". (C 2045 model shown)

Emergency operation of shut-off valves

The shut-off valve activates and close, when the safety feature becomes operational in the event of an accident, and in case a solenoid has become defective or its electrical circuit is interrupted. In that case, the engine is out of service. In order to restore the fuel supply in that case, the fuel shut-off valve has been equipped with an emergency lever.

To restore or open fuel supply using manual lever

Push the lever and turn slightly further than a quarter of a turn clockwise, prime system.

To return valve to normal operation

Turn the lever slightly further than a quarter of a turn counterclockwise.

