

COACH MODEL

Any

DATE

12.30.2025

SUBJECT

How to Wash & Maintain ABC RockGuard

Maintaining the exterior finish of your coach could require a unique level of care and attention that you may not be familiar with—and that's okay! This Tech Tip outlines the measures that should be taken to properly maintain **ABC RockGuard**—your resilient paint protection film.

Wait 48-Hours



After installing the protection film, wait 48-hours before washing your coach.

Pressure Washing Precautions



- **DO NOT** use a **red** or **yellow** tip when pressure washing.
- Avoid pressure washing near the edges of the film.

Remove Stains



Use film cleaner to remove stains. For tougher stains, use 99% isopropyl alcohol **ONLY** on the film.

Self-healing Properties



At room temperature, light scratches will self-heal within 20–30 minutes. In colder conditions, pour hot water (~120°F) over the affected area.

Seal Coat



To best preserve the high-gloss film, apply a coat of ceramic sealant to your coach every 6-months.

Remove Contaminates



Remove various contaminants and defects using detailing clay.