



CX35 | CX45

Driver's Guide

VIN#

LEFT CONSOLE PANEL

- 1 Cup Holder
- 2 Mirror Adjustment
- 3 Parking Brake Control
- 4 USB Socket
- 5 12V Light
- 6 Microphone Socket
- 7 Aux Brake Cut-Out
- 8 Emergency Cut-Out Switch
- 9 Park Brake Emergency Release

DOOR CONTROLS

- 1 Blank (Option)
- 2 Entry Door Emergency Air Release

CONTROL PANEL IN ENGINE COMPARTMENT (CX35 ONLY)

- 1 Start Engine Button
- 2 Stop Engine Button
- 3 Force Regeneration
- 4 Regeneration Inhibit
- 5 24V Socket

CONTROL PANEL IN ENGINE COMPARTMENT (CX45 ONLY)

- 1 Start Engine Button
- 2 Stop Engine Button
- 3 Force Regeneration
- 4 Regeneration Inhibit
- 5 Toilet Tank Dump Valve
- 6 Waste Tank Dump Valve

INTERIOR WHEELCHAIR LIFT COMPARTMENT

- 1 Lift Lighting
- 2 Lift Door Emergency Air Release Knob
- 3 Lift Door Emergency Handle
- 4 Belt Cutter

WHEELCHAIR LIFT

Manual Bypass Knobs

- 1 In
- 2 Out
- 3 Up
- 4 Down
- 5 Power
- 6 Switch

Control Pendant

- 1 Up
- 2 Down
- 3 Stow
- 4 Deploy

This guide applies to Van Hool CX models, year 2023 and newer.
Vehicle specifications subject to change without notice. All information, illustrations, and specifications contained in this guide are based on the latest product information available at the time of production. The right is reserved to make changes at any time without notice.
Please refer to all owner, operations, maintenance, or parts manuals and associated documentation for further information.



ABC Customer Care | Service 24/7

ABC CustomerCare | Van Hool Technical Support | Emergency Roadside Assistance
Toll Free 877-427-7278 www.abc-companies.com/care

CX35 | CX45

Driver's Guide

LEFT HAND DASHBOARD

- 1 Blank
- 2 Blank
- 3 ACC (Option)
- 4 Transmission Shift Pad
- 5 CMS (Option)
- 6 LDW On/Off Switch
- 7 Master Switch
- 8 Ignition Switch
- 9 ASR (Traction Control)



COMBINATION SWITCH ON STEERING COLUMN

- 1 Turn Signal, High/Low Beam Lever
- 2 Windshield Washer
- 3 Horn
- 4 Windshield Wiper Control



DRIVER'S FLOORBOARD AREA

- 1 Steering Column Adjustment



SMART WHEEL

- 1 Cruise Control
- 2 Flash High Beam Headlights
- 3 Engine Brake Settings



CENTER INSTRUMENT PANEL

- | | |
|--------------------------------------|-----------------------------------|
| 1 Left Turn Signal • | 16 Direction Indicators (Trailer) |
| 2 Parking Brake • | 17 Alternator • |
| 3 Collision Warning • | 18 Air Pressure Aux Tank |
| 4 High Beams • | 19 Fog Light • |
| 5 Electronic Stability Control (ESC) | 20 High Exhaust Temp. Warning • |
| 6 Stop Lamp • | 21 Master Switch |
| 7 Malfunction Indicator Lamp • | 22 Fault Retarder • |
| 8 Anti-Lock Brakes ABS Stop • | 23 Speedometer |
| 9 Engine Warning • | 24 Engine RPM |
| 10 Brake Wear Sensor • | 25 Tank Pressure |
| 11 Right Turn Signal • | 26 Oil Pressure |
| 12 Headlights On | 27 Coolant Temp |
| 13 Door State •/• | 28 DEF Level |
| 14 Adaptive Cruise Control Warning | 29 Fuel Level |
| 15 Baggage Door Open | |



RIGHT SWITCH PANEL

- | | |
|-------------------------------------|----------------------------|
| 1 Door Open/Close | 21 Left Driver's Sunshade |
| 2 Luggage Bay Lock | 22 Right Driver's Sunshade |
| 3 Safety Media Player (Option) | 23 Driver's Light |
| 4 Kneeler | 24 Reading Light |
| 5 Rear Raising | 25 Passenger Lighting |
| 6 Full Lift and Lower | 26 Passenger Night Light |
| 7 Tag Axle Unload (Option) | 27 Blank |
| 8 Hazard Warning Signal | 28 Blank |
| 9 Fire System Mute and Delay | 29 Luggage Bay Light |
| 10 Driver's Fan Speed | 30 REI Radio Control Unit |
| 11 Driver's Temperature Control | 31 SmarTire Monitor |
| 12 Driver's Area Recirculate Switch | 32 12V Adapter Charge Port |
| 13 AC On/Off Switch | 33 USB Adapter Charge Port |
| 14 Passenger Temperature Control | 34 Auxiliary Heater On/Off |
| 15 Passenger Recirculate Switch | 35 Blank |
| 16 Blank | 36 Pass. SOS Alarm On/Off |
| 17 Exterior Lights | 37 Wheelchair On/Off |
| 18 Fog Lamps | 38 120V AC On/Off |
| 19 Cornering Lamps | 39 High Idle On/Off |
| 20 Sidewalk Lighting | 40 Engine Override |
| | 41 Blank |

