



COACH MODEL
DATE
SUBJECT

2026 VanHool CX45
01.16.2026
Be-Ge Driver's Seat Operation Guide (3110R-B)



- 1 Seat Cushion Adjustment**
(Adjustment length: 80mm) LIFT the lever and adjust the seat cushion forwards/backwards.
- 2 Horizontal Adjustment**
(Adjustment length: 210mm) LIFT the sliding mechanism and adjust the seat to the desired length.
- 3 Seat Back Adjustment**
LIFT the lever and lean forward/backward to adjust the seat back angle. RELEASE the lever upon finding the desired angle.
- 4 Armrest**
Use the armrest adjustment knob to adjust the angle of the armrest. The armrest may also fold up or down as necessary.
- 5 Safety Belt (Seat Belt)**
(2-, 3- or 4-point belt) Please secure yourself to the seat by affixing the safety belt (seat belt) to the belt buckle.
- 6 D-Loop**
PRESS the knob to adjust the height of the upper belt portion.



7 Seat Cushion Tilt

LIFT the lever and adjust the seat cushion as necessary. Press DOWN on the lever upon finding the desired angle.



8 Height Adjustment

(Adjustment height: 100 mm) To RAISE the seat, lift the lever UPWARDS.

To LOWER the seat, press the lever DOWNWARDS.



9 Adjustable Shock Absorber

LIFT the lever to the UP position to INCREASE shock absorption. PUSH the lever to the DOWN position to DECREASE shock absorption.



10 Air Ventilation

Switch the button to the ON/OFF position to control air ventilation.



11 Seat Heating

Set the button to position "O" (off), "I" (level 1), or "II" (level 2).

Thermostat controlled
Level 1: 10/20°C on/off (comfort heating)
Level 2: 28/37°C on/off
Supply: 24 V, 50W
Supply: 12 V, 13W



12 Lumbar Support

Press "+" to increase lumbar support.
Press "-" to decrease lumbar support.



13 Air-Controlled Side supports

Press "+" to increase side support.
Press "-" to decrease side support.



14 Air-Controlled Shoulder Support

Press "+" to increase shoulder support.
Press "-" to decrease shoulder support.